

BrightSign®

BRIGHTAUTHOR RELEASE NOTES

Version 4.3.0.16

BrightAuthor Requirements

- PC with Windows Vista or Windows 7, plus Microsoft .Net Framework 4.0 or later
- BrightSign 4Kx42, XDx32, XDx30, HDx20, LSx22, AU320

Minimum Firmware Required: 5.1.33

- BrightSign HDx22

Minimum Firmware Required: 5.1.16

Help and Feedback

If you would like to learn more about the new BrightAuthor features described below, please download the [User Guide](#). If you are new to BrightAuthor, you can also visit the [Training](#) page. If you have any questions, please contact us at support@brightsign.biz.

Changes Since 4.3.0.13

Bug Fixes

- BrightAuthor will no longer display an error message if you close the application with the **Create** tab selected, reopen it, and attempt to add a video file to a Dynamic Playlist.

- BrightAuthor will no longer crash if you create device setup files with the **Custom Splash Screen** option selected, then switch to **Standard Splash Screen** and try to create device setup files again.

Improvements

- Playback will no longer wait for an MRSS feed or Dynamic Playlist to fully download. Instead, when the playlist reaches an incomplete media feed, it will skip the state.